Digital Knight Heat Platen Tension Plate Adjustment

<u>To adjust the tension of the heat platen</u> (therefore increasing or decreasing curvature of platen):

- 1. Remove the 4 nuts in the center of the heat platen.
- 2. Lift the cover up from the press.
- 3. It may become necessary to disconnect the heat platen from the head. Simply turn the pressure knob to the left until the heat platen drops onto the rubber pad.
- 4. There is a square steel 2" block in the center of the heat platen. Remove the steel block off the 4 threaded studs. It is sitting on 4 lock nuts.
- 5. Slight adjustments (1/2 turn at a time ONLY) to these nuts increase or decrease the amount of tension and curvature of the heat platen. ALWAYS MAKE EQUAL TURNS TO ALL FOUR NUTS, otherwise the levelness & tilt of the heat platen is affected:

<u>Turning all four nuts to the left / counterclockwise</u> will decrease the tension & curvature.

Turning all four nuts to the **right** / clockwise will **increase** the tension & curvature.

6. The goal is to come within 1/32 of an inch curvature to the heat platen. More than this will affect the amount of pressure in the center adversely. A slight amount of curvature MUST be in the platen, or the outer edges can loose pressure over extended periods of time during the life of the press.