## Pressure & Flatness Check

- 1. Please check the flatness of the bottom rubber padding. Take a 2ft long straight edge and gently rest it on the pad, front-to-back along the 20" dimension, down the middle. Any daylight, gaps, spaces? It should be pretty flat and gapless.
- 2. Do the same on the top heat platen, holding the straight edge against the top heating surface. There should be about a dime's space or less. NOT a nickel!
- 3. Please send me a 5 to 10 second short Small VIDEO clip of the press being closed and locked, and popping back open. From the side view. Make sure I see the whole press and the operator's arms locking it. Then I'll know how it's closing and locking and opening. Set the timer for like 4 seconds or something.