

Quick Instructions for 2022 version Bottom Heat Attachment



Remove the U bracket and ¼" plate from the base used for the all-thread tables. Then attach this ¼" mounting plate using the (2) 5/16-18 allen flat heads into the (2) tapped holes in the base. *same allen key used to remove the U bracket/plate works for fastening the flat heads.



Then simply flip the bottom heat unit over and attach using (2) 5/16-18 screws "outside the frame area for easy tightening.