

# Operator Lockout Setting

Turn press OFF.

Hold TEMP & PRG keys down firmly.

Turn press ON – keep holding TEMP & PRG.

Let go when “Firmware/302” or something like that shows.

Press PRG repeatedly until “LOK” shows.

Use arrow keys to set to “OFF” or “ON” depending on if you want the keypad locked or not.

Press PRG repeatedly until the normal temp/time screen comes on, and test it.