

Digital Knight Swing-Away Stop Collar Position Adjustment

The swing-away press heat platen can be adjusted to stop precisely where the user needs it to, over the bottom table.

If the press is swinging too far past the bottom rubber pad before it stops – make the following adjustment so that it stops directly over the bottom rubber pad:

1. Look at the rear white swivel post on the back of the press.
2. Locate the SILVER METAL COLLAR that is wrapped around the rear white post.
3. This Silver Metal STOP COLLAR is what stops the head from swinging.
4. There is a large Black Allen Bolt that TIGHTENS the Silver Metal Stop Collar around the rear white post.
5. LOOSEN this black allen bolt so that the silver metal collar can be moved and rotated around the white post.
6. Swing the press over the rubber pad so that the heater aligns with the rubber pad.
7. Move the Silver Metal Stop Collar so that it HITS & CONTACTS the post it normally does.
8. TIGHTEN the large black allen bolt, and test the press to confirm it is stopping where you need it to stop. Repeat the adjustment if fine tuning is desired.

