



TEMPERATURE

The Maxi-Press is equipped with a dual display digital temperature control unit. The Ogden control indicates both set point temperature and actual temperature. The set point temperature appears in lower “green” display. The actual temperature appears in the upper “red” display. Your machine was factory set at (400 degrees Fahrenheit) Please review the below section to increase or decrease the set point temperature.



Ogden temperature control

To increase: To increase the temperature, simply push the “up” arrow located on the control unit.

To decrease: To decrease the temperature, simply push the “down” arrow located on the control unit.



Caution: Do not press the control loop keys located on the lower left and lower right of the ogden control unit. Only use these keys to change internal settings. This should only be done while working with a Geo. Knight factory technician.



Note: The normal heat up time for the Maxi-Press is approximately 20-30 minutes, depending on heater block size and inlet voltage.

The Maxi-Press has a thermal runaway alarm circuit the event that the actual temperature is 25 degrees Fahrenheit higher than the set point temperature. The temperature buzzer audible alarm will sound until the condition is cleared or the power is turned off.