

DK20S Handle Arm Screws

GUIDELINES:

There are TWO ¼-20 x 1" Allen Screws in between the two rubber handle-grips that hold connect the handle bar to the two arms from the two clamps on the press.

RULE 1: If these two allen screws are tight – they'll last forever and cannot break.

RULE 2: If these two allen screws are loose – they can shear and break easily if the press is used heavily while the handle bar is loose.

**** Always make sure the two handle bar screws are tight.**

**** If they loosen up regularly, use plenty of RED LOCTITE on the screws and let it cure overnight to lock them in place.**

REPAIR:

If a screw breaks, there are two options:

1. Get a screw extractor tool from home-depot/lowes if needed, or try unscrewing the broken piece with needle-nose pliers. Either way get the old screw out, and then use ¼-20 x 1" ALLEN SCREWS (the most common allen screw out there) and RED LOCTITE and let it cure overnight to lock it in TIGHTLY.
2. If the screw cannot come out...
Please go to www.heatpress.com/support and order from the parts list:

MEN-DK20SARM (2 pcs)
FAS0AN14201 (2-pcs - NO charge)

They are in stock and usually ship out the same day...