

# DK20S Sticking Clamps Troubleshooting

1. Clean the two silver posts super clean and dry, opening and closing and cleaning the top half and bottom half of the silver posts.
2. You can use any type of White Lithium Spray grease (home-depot/lowes) – Just a LITTLE BIT – on the silver posts.
3. Loosen the 8 silver bolts holding the 2 clamps onto the white head so both black clamps are super loose and free, and use the press for a while. Then – clamp the press with medium pressure and TIGHTEN the 8 silver bolts back up. That will recenter it.

Let us know how that goes first, and if there's still trouble – email a short small (LESS THAN 25MB) VIDEO CLIP of the press from the side view opening and closing the press. Let us see the ongoing sticking issue and the whole press and operators arms, from the side.